

Installation guide for Honda DelSol



Original Roof



Side By Side—Original Roof & Sunroof



Disassemble Original Roof



Remove the 3 10mm nuts from front of each rail



Remove the 4 10mm nuts from Rear of each rail



Original Roof Disassembled



Install New Rails on the Sunroof



**Install the plastic garnish on the new roof -
note, the front-center piece didn't snap in place until the metal tabs were bent/expanded so they could catch**